

Installing the Penny Plug

Your new Penny Plugs are custom designed to fit perfectly into your column style coin dispenser. The Penny Plugs will replace the physical penny stack and allow the coin dispenser to function while bypassing the penny low coin sensor.

STEP 1 – Unplug or disconnect the power to the coin dispenser.

STEP 2 – Unlock the coin cover or cassette so the coins can be removed.


STEP 3 – Remove all pennies from the dispenser.

STEP 4 – Insert a Penny Plug into each penny column.

STEP 5 – Replace the coin cassette or carousel back into the dispenser and turn on.

NOTES:

- The new Penny Plug should freely go into the empty Penny slot and be placed at the lowest part of the column.
- You cannot mix pennies with the Penny Tubes or have pennies in some columns and not the others as the dispensers cannot detect real pennies from Penny Tubes.
- You may need to adjust the coin balance for your dispenser after removing the pennies.



CPI TeleQuip Cassette (Left) and Glory (Talarus) InstaChange Carousel (Right) shown with Penny Plugs installed.